

Pop-Up Tent Instructions

HOW TO INSTALL



Partially open the frame so that all four corners are accessible.



Place canopy on the frame and firmly attach velcro in all four corners.



Pull open the tent until it locks into position.



Adjust leg height as needed



Once Adjusted, you may add the back wall graphic and half side wall graphics.

