

Packing Tips


Ease of use was a primary goal of the Abex 300 Series award-winning case design. Use these tips as a guide to simplify your teardown and repacking.

- Make sure frame strap is around frame prior to packing.
- Pack frame in frame bag, channel bars into padded channel bar bag, and any accessories into their respective bags.
- Case to Table Conversion for 4200 Series Only: Ends of skirt roll up in panel case before all other panels. Front and back of skirts go in last.
- Case to Pedestal Conversion for 4100 Series Only: When packing in cylindrical case, ends of skirt roll up in case first. Front and back panels go in next. Top goes in last.
- Always roll up panels in sets of two, fabric to fabric. (Exception: Roll up curved frame end panels in sets of two [with a liner between] fabric side out.)
- Do not roll panels too tight. Damage may occur to the magnetic strip adhesive.
- A liner is included if there is an odd number of panels.
- Use the liner as a divider between panels and hardware when packing tabletop displays.
- Photomural panels must always be individually rolled image side out with the slip sheets that are provided.
- Cases may be strapped together for easy transport.
- The following pages diagram packing locations for the majority of the Abex 200, Abex 300 and Abex 350 product line. You may receive specific packing instructions should you have a custom display.

PACKING




4100 PACKING INSTRUCTIONS



PACKING

4200 PACKING INSTRUCTIONS




PACKING



4300 INSTRUCTIONS & PACKING

Case Shelf



Open the case lid and lower the hinged shelf into position. Shelf may be removed if desired.

SHIPPING



Abex ships via U.P.S Ground unless specified otherwise. Please remember to calculate shipping time when discussing delivery with your client. U.P.S. and Federal Express Rate and Zone charts follow for your convenience.

If an order does not arrive by the due date please call our offices immediately so that a tracer can be placed.

Freight charges are added at the time of shipping and/or invoicing.

Please check your order for damage or discrepancy upon receipt. Abex must be notified of any discrepancies within two weeks of receipt of shipment.

Abex Display Systems, Inc.
7101 Fair Avenue
North Hollywood, CA 91605
(818) 764-5126 • (800) 537-0231

Shipping Guide

Box Size	Dimensions	Dimensional Weight for Air Shipments $\frac{L \times W \times H}{194}$	Dimensional Size for Ground Shipments Over 84" / Max 130"
4100	38 1/8" x 13 3/4" x 19 1/4"	15lbs/7.03kg	107"
4200A	39 5/8" x 20 3/8" x 13 1/2"	26lbs/11.8kg	112"
4200B	39 5/8" x 20 3/8" x 17 5/8"	24lbs/10.9kg	120"
4300	38" x 28 1/8" x 16 3/8"	45lbs./20.4kg	130"
4102 Cylinder	42 3/4" x 13 1/2" x 13 1/2"	7.1lbs/3.2kg	100"
4103 Pedastal Cylinder	24" x 13 1/2" x 13 1/2"	22lbs/9.9kg	77"
4106 Ultra Lite	17 1/2" x 16-1/2" x 36 1/4"	54lbs/24.5kg	107"
Graphics Box	8" x 8" x 36"	12lbs/5.4kg	68"
5PCC Panel Case	10" x 48" x 25"	26lbs/11.8kg	130"
Header Box	24-1/2" x 4" x 48"	25lbs.	106"
ABEX 200, 300, 350			
ABEX 500, 600, 900			

Example

Minimum weight charge for a 4100 box:
Air = 57lbs/26kgs • Ground = 30lbs/14kgs

Air = Next Day, 2nd Day
Ground = 3 Day Select, Groundtrack, Ground